

Diagram A
Gauge Dimensions

Merchandise warranted against defects in factory workmanship and materials for a period of 24 months after purchase. This warranty applies to the first retail purchaser and covers only those products exposed to normal use or service. Provisions of this warranty shall not apply to a VDO product used for a purpose for which it is not designed, or which has been altered in any way that would be detrimental to the performance or life of the product, or misapplication, misuse, negligence or accident. On any VDO part or VDO product found to be defective after examination by manufacturer, manufacturer will only repair or replace the merchandise through the original selling dealer. Manufacturer assumes no responsibility for diagnosis, removal and/or installation labor, loss of vehicle use, loss of time, inconvenience or any other consequential expenses. The warranties herein are in lieu of any other expressed or implied warranties, including any implied warranty of merchantability of fitness, and any other obligation on the part of manufacturer, or selling dealer.

(NOTE: This is a "Limited Warranty" as defined by the Magnuson-Moss Warranty Act of 1975.)

#1 BEGIN HERE

CAUTION: Read these instructions thoroughly before making installation. Do not deviate from assembly or wiring instructions. Always disconnect battery ground before any electrical connections. If in doubt, please contact your dealer or VDO instruments at 1-800-264-1818

General Information:

Your VDO mechanical vacuum gauge features the latest illumination technology and a rugged design to insure years of durable and reliable operation. These instruments require a tubing kit to complete installation with

Parts List

Item	Description	Quantity
1.	Vacuum Gauge (2 5/8 [52mm] diameter)	1
2.	Lamp Socket	1
3.	Light Bulb	1
4.	VDO Mounting Bracket and Nuts	1
5.	Installation Instructions	1

Tools and Materials Needed for Installation:

16 Gauge stranded, insulated wire
Insulated 1/4" spade connectors
2 5/8" hole saw
Drill and drill bit set
Half-round file
Tape measure or ruler
Small tools: wrench or nut drive, utility knife, pliers, etc.
Tubing kit and various engine adapters

various engines. You may purchase such a kit (with different lengths of tubing and of different styles) from your VDO dealer

Gauge Installation:

1. Select the location where you will mount the gauge, and mark a center point for a hole (or use a VDO Mounting Accessory [1,2, & 3 hole chrome and black] or a VDO Mounting Cup [chrome or black].
2. Cut a 2 5/8" (65mm) diameter hole for the vacuum gauge. Place the instrument into the hole. If the gauge is too snug, use a file to slightly enlarge the opening until the gauge fits properly. See Diagram A.

3. Slip the mounting bracket over the mounting bolts on the back of the gauge. Screw on the accompanying nuts. Tighten the nuts until the gauge can no longer be rotated by hand. **DO NOT OVERTIGHTEN!**

CAUTION!!!!

The bezel diameter is only a few millimeters larger than the gauge itself. With that in mind, measure and precisely mark the gauge location before cutting any holes!

VDO

Mechanical Vacuum Gauge Installation Instructions

Instruction Sheet #0 511 011 795
09/09

INSTRUCTIONS FROM THE INSTALLATION OF THE MECHANICAL VACUUM GAUGE ARE CONTAINED HEREIN. USE IS RESTRICTED 12-VOLT NEGATIVE GROUND ELECTRICAL SYSTEMS. LIGHT BULB, IF SUPPLIED IS 12-VOLT

To Begin, go to #1

#2 CONTINUE HERE

Gauge Hook up and Lamp Wiring:

1. Route the tube from the gauge to the engine. DO NO CRIMP the tubing closed during routing. A rubber grommet is recommended around the tubing where it passes through the firewall.

2. Attached one end of the tubing to the gauge using a 1/8" adaptor, ferrule and sealing nut, as shown in Diagram B.

3. Attach the other end of the tubing to the engine using a T-fitting, 1/8" adaptor, a ferrule and a sealing nut.

DO NOT OVERTIGHTEN THE SEALING NUTS OR YOU WILL DAMAGE THE TUBING!!!

4. Run the wire from the gauge lamp socket to the lighting circuit (a + 12 volt source, usually after the light switch fuse in the fuse box). See Diagram B

At this point, installation is complete. Re-check the routing of the tube from gauge to the engine.

CAUTION:

Make sure the tube is absolutely free from moving and/or hot engine components, and that is totally free of kinks.

Start the engine and turn on the lights to make sure the gauge illumination functions properly. If it doesn't, recheck your connections and your wiring. Check all tubing connections for leaks.




Diagram B
Gauge hookup and lamp wiring information