

# **Installation Instructions**

## **PN 118266A1**

**When installing this replacement temperature gauge, verify that connections are made per the following procedure:**

- 1. Remove wires from 3 cavity connector**
- 2. Replace terminals with appropriate ring style terminals.**
- 3. Connect:**
  - a. Orange wire to "+" B+ on gauge**
  - b. Purple wire to "S" Sender on gauge**
  - c. Black wire to "-" Ground on gauge**

**NOTE: If harness has previously been modified with ring terminals, please reconnect per the scheme shown above.**